



Dodge Ram

Install Universal Mounts
on Vertical Steering
Column Studs



Attach Main Arm



Run Accelerator Cable
to the Right of Control at
Top Portion of Panel



Attach "P" Clamp to
Vertical Plate About 6"
Inches in front of
Existing Accelerator
Pedal Cable.



Use Self Tapping 1/4"
screw. Attach Cable to
Accelerator Pedal Per
Page 8 Figure #9. See
Page 10 Figure #15 for
"P" Clamp Adjustment

Use Instruction Manual
For Brake Tube
Hook-Up.