



Use Universal Mounting  
for Placement of Pivot  
Arm & Control Arm



Standard Brake and  
Accelerator Hookup

